



# Closing the swimming pool

---

## After the swimming season and before closing

1. Clean the canvas, the ladder and the various accessories with PLUS 9 and the solar blanket with SPEED.
2. Install the canvas or net as needed.

## A week, or a few days, before closing

3. Perform a water analysis to balance it. The ideal pH should be around 7.8.
4. Brush the walls of the pool and vacuum.
5. Clean your filter with KLEAN FILTER.

## When closing:

6. Empty the pool by about half.
7. Use the closure kit and leave to act for 4 to 5 hours.
8. Drain the filter and the pump. Pour ½ liter (500mL) of antifreeze into the filter and 1 to 2 liters into the pump basket.
9. Remove eye and return water ring. Put on the wintering cap.
10. Remove the door and the basket from the skimmer.
11. Insert the "foam" kit into the skimmer.
12. Put the pump and the pressure gauge inside. Place a plug in place of the pressure gauge.
13. Put the filter valve in the winter position and put a plastic bag on it.

## Preparing the bottom drain for winter

1. Adjust the 3-way valve, under the skimmer, to the PUMP CLOSED position
2. Pour 4 liters of pool antifreeze into the bottom drain pipes.
3. Insert etafoam into the pipe.
4. Place the 3-way valve in the MAIN DRAIN position.
5. On the 3-way valve, place a plug on the outlet going to the pump.
6. Pour some antifreeze into the valve.
7. Insert the "foam" kit into the skimmer.
8. Replace the skimmer cover.
9. Wrap the skimmer in a plastic bag.



370 avenue D'Amours  
Matane (Québec)  
G4W 2X9  
web: www.aqua-pur.ca

Tel: 418-562-4118  
418-566-6868  
Fax: 418-566-6363  
Email: aqua-pur@hotmail.ca

## Filter cleaning procedure with KLEAN FILTER

1. Do a BACKWASH.
2. Stop the pump.
3. Close the valve under the skimmer
4. Put the filter in the CLOSED position
5. Remove the pump cover
6. Empty the KLEAN FILTER product. Stir the product with the water contained in the pump.
7. Replace the pump cover.
8. Put the valve back under the skimmer halfway.
9. Return the filter to the FILTRATION position.
10. Start the pump for 15 to 20 seconds, while the product transfers to the filter.
11. Leave the pump closed for 12 hours.
12. After 12 hours, put the filter in the BACKWASH position and restart the pump.

Your filter is now clean.

For those who do not have a valve under the skimmer and a CLOSED position on their filter, put a cloth in the skimmer and one in the water return. This will ensure that water does not flow back into the pump. The rest of the procedure is the same.

For those who have a chlorine generator (salt system), clean the cell with CELL SAVER if necessary.

Inspect your cell:

1. There is a deposit on the platelets, clean your cell with the acid cleaner. We can do the cleaning for you.
2. There is nothing, rinse it with water.